

IMPORTANT: If parts are missing please contact the manufacturer at 1-800-665-7487.



Congratulations!

You are the proud owner of a Fish Inn Ice Fishing Shelter. Your Fish Inn is fully assembled and ready to set up on the ice.

IMPORTANT: Save these instructions – **DO NOT DISCARD.**

PARTS INCLUDED:

- 2 spare poles
- 1 Tie Down Strap
- 5 ice anchors
- Carry and Storage Bag

LONG TERM STORAGE

Please make sure your Fish Inn is completely dried out after each use and before storing for long periods of time. Store shelter in a cool, dry place away from rodents.

SAFETY AND MAINTENANCE

Please fully understand and follow all safety instructions outlined below. Failure to do so could result in severe injury or death.

- Do not use open flame heaters in your ice shelter, injury or death may result from fire if tent fabric is exposed to open flame.
- Never leave shelter unattended when set up
- Use extra tie downs during excessive winds

• Due to traffic on lakes, ice fishing can be hazardous at night. If you choose to fish at night or in conditions with poor visibility, be sure to take precautions with lights or reflectors.

Exterior reflectors must be visible to reduce risk of collisions.

WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS TENT FABRIC.

This tent is made of flame-resistant fabric. It is not fireproof. The fabric will burn if left in continuous contact with a flame source. Death from asphyxiation may result from use of oxygen depleting heaters. Open all vents for fresh air ventilation.

This tent is made with flame resistant fabric which meets CPAI-84 specifications.

WARRANTY INFORMATION

Equinox Industries Ltd. warrants to the original retail purchaser that all Fish Inns are free from manufacturer's defects for one year from the date of the original purchase. Warranty does not cover cracked windows, tent tears, broken or bent hoops due to high wind weather conditions or unattended use. All parts

must be returned to Equinox. Before returning you must first call Equinox or email and acquire a return authorization. All returns must be returned postage-prepaid and included the original cash register receipt (date and purchase price).



Toll Free (U.S.A.): 1-800-563-3352
Toll Free (Canada): 1-800-665-7487
Fax: (204) 694-7133
E-mail: info@eqnx.biz

www.eqnx.biz


Setup Instructions

1




Step 1: Remove ice shelter from the carrying bag. Remove pouch with anchors and straps. Remove tie strap from around the shelter.

2




Step 2: Lay the ice shelter on the ground and check that there is no material twisted or overlapping the ends of any poles.
****Tip -** Watch for entanglement of poles. **DO NOT** force shelter when unfolding or folding. Excessive force could cause breakage of poles. 2 spare poles are included.

3




Step 3A: Pull outward on the loop on one of the walls. Continue around the entire shelter pulling each loop outward on wall hub until all sides are popped out.
****Tip -** Place your foot on the ground skirt to help hold the shelter in place when popping open the walls




Step 3B: From inside the shelter, push upwards on the roof hub until it pops into place.

4



Step 4A: Position the shelter over fishing hole in ice and secure each loop on inside corners/walls of ice shelter to ice using the provided ice anchors.
****Tip -** Push down while twisting ice anchor until it gets started and then twist the anchor until it holds fast.




Step 4B: Find the side of the shelter that faces into the wind and attach the strap provided. Stretch the strap into the wind and with the remaining anchor secure the strap to the ice.
****Tip -** Shovel snow onto the skirt around the entire fishing shelter.

Take Down Instructions


1

****Tip -** Zip all doors shut. Do not leave them open. Close all windows and vents. Remove all ice and snow from the shelter before take down.




Step 1: Unscrew the ice anchors from the inside corners/walls and remove tie down(s) from the outside wall(s). Place all anchors and straps in the supplied pouch and store in the carrying bag.

2




Step 2: Using your hand, push in center hub on one outside wall until it collapses inward. Continue around the outside of shelter collapsing all remaining walls.

3




Step 3: Using your hand, push in center hub of roof until the roof flattens down onto the sides.

4



Step 4: Once the unit is lying flat, lift each of the corners together and stand the folded unit with all of the hubs facing down.

5



Step 5: Lay the collapsed shelter down and use the strap to secure all sides.

6



Step 6: Place the shelter into the carrying case hubs first. Place the pouch with the ice anchors and tie down straps into the carrying case as well.